

▪ EFG and SPG particle plotting in LS-PREPOST

- Click on “**Model and Part**” and then “**Appearance**” from the right-hand side options
- In “**Appearance**”, check “**Sphere**” and “**Shrn**”, then click on target parts (Mesh should turn to grids)
- Choose “**Settings**” and then “**General settings**” on top menu bar
- In “**General settings**”, check “**SPH/Particle**” and set appropriate values of “**Radius**” and “**Divs**”
- In “**General settings**”, choose “**Smooth**” as “**Style**” and check “**Fixed Radius**”, then “**Apply**”

